

FURUNO

OPERATOR'S MANUAL

MULTI-PURPOSE LCD DISPLAY

MODEL MU-120C



FURUNO ELECTRIC CO., LTD.

www.furuno.co.jp



SAFETY INSTRUCTIONS

Safety Instructions for the Operator



WARNING



Do not open the equipment.

Only qualified personnel should work inside the equipment.

Do not disassemble or modify the equipment.

Fire, electrical shock or serious injury can result.

Use the proper fuse and power cable.

Fuse rating is shown on the equipment. Use of a wrong fuse can result in damage to the equipment.

Immediately turn off the power at the switchboard if the equipment is emitting smoke or fire.

Continued use of the equipment can cause fire or electrical shock. Contact a FURUNO agent for service.




CAUTION

Do not connect/disconnect the signal cable while turning the power on.

The unit may be damaged.

A warning label is attached to the equipment. Do not remove the label. If the label is missing or damaged, contact a FURUNO agent or dealer.



Name: Warning Label (1)
Type: 86-003-1011-1
Code No.: 100-236-231

Safety Instructions for the Installer



WARNING



Do not open the cover unless totally familiar with electrical circuits and service manual.

Improper handling can result in electrical shock.

Turn off the power at the switchboard before beginning the installation.

Fire or electrical shock can result if the power is left on.

Do not install the equipment where it may get wet from rain or water splash.

Water in the equipment can result in fire, electrical shock or damage to the equipment.



CAUTION

Observe the following compass safe distances to prevent interference to a magnetic compass:

	Standard compass	Steering compass
LCD Monitor MU-120C	0.75 m	0.5 m
Remote Controller RMC-200	0.3 m	0.3 m

When lifting the display unit, hold it together with the cover.

Grasping by the cover alone may allow the display unit to fall, resulting in possible bodily injury or damage to the equipment.

TABLE OF CONTENTS

FOREWORD	iii
SYSTEM CONFIGURATION.....	iv
EQUIPMENT LISTS	v
1 MOUNTING	1
1.1 Display Unit.....	1
1.2 Remote Controller	4
2 WIRING.....	5
3 ADJUSTMENTS	7
3.1 RGB/DVI Setting	7
3.2 VIDEO Setting.....	9
3.3 Menu Window Setting	10
3.4 Remote Controller Setting	12
4 OPERATION.....	13
4.1 Controls.....	13
4.2 Adjusting Display Brilliance.....	15
4.3 Choosing Source for Main Picture	16
4.4 Choosing Source for Picture-in-Picture.....	17
5. MAINTENANCE, TROUBLESHOOTING.....	18
5.1 Maintenance.....	18
5.2 Troubleshooting.....	19
5.3 Clearing the Memory	20
SPECIFICATIONS.....	SP-1
PACKING LISTS	A-1
OUTLINE DRAWINGS	D-1
INTERCONNECTION DIAGRAM	S-1

FOREWORD

A Word to the Owner of the MU-120C

FURUNO Electric Company thanks you for purchasing the MU-120C 12.1" Multi-Purpose LCD Display. We are confident you will discover why the FURUNO name has become synonymous with quality and reliability.

For over 50 years FURUNO Electric Company has enjoyed an enviable reputation for quality and reliability throughout the world. This dedication to excellence is furthered by our extensive global network of agents and dealers.

Your equipment is designed and constructed to meet the rigorous demands of the marine environment. However, no machine can perform its intended function unless properly installed and maintained. Please carefully read and follow the operation, installation and maintenance procedures set forth in this manual.


We would appreciate feedback from you, the end-user, about whether we are achieving our purposes.

Thank you for considering and purchasing FURUNO.

Features

- Main or remote display for radars, video sounders, sonars, plotter. Compatible equipment: FAR-21X7 series, MODEL1833C/1833C-BB series (NavNet), FCV-1200L, CH-250, CH-270, CSH-5L/8L, GD/GP-280/380/680, etc.
- High resolution display of 800 x 600dot (SVGA)
- Brightness of 1,000 cd/m² (maximum) and 5 cd/m² (minimum) for comfortable viewing day and night
- Landscape orientation
- Wide viewing angle for observation by more than one person
- Picture-in-picture function

SYSTEM CONFIGURATION



Connectable equipment

Equipment	Resolution	Signal
FR-1510 MK3 series	XGA	Analog
FCV-1200L*	VGA	Analog, via IF8000
GD/GP-280/380/680	VGA	Analog
CH-250	VGA	Analog, via IF8000
CH-270	VGA	Analog, via IF8000
CSH-5L/8L	XGA	Analog
FSV-24/24S/30/30S	SXGA	Analog
FR-21X5 series	SXGA	Analog
FAR-21X7 series	SXGA	DVI
FEA-2107	SXGA	DVI
MODEL 1833C series	VGA	Analog
MODEL 1833C-BB series	VGA	Analog

*= Not available for the portrait type.

Note: The resolution of MU-120C is SVGA. VGA, XGA and SXGA signal may not be sharp in character or scan line.

About the TFT LCD

The TFT LCD is constructed using the latest LCD techniques, and displays 99.99% of its pixels. The remaining 0.01% of the pixels may drop out or blink, however this is not an indication of malfunction.

EQUIPMENT LISTS

Standard supply

Name	Type	Code No.	Qty	Remarks
Display Unit	MU-120C	–	1	w/LCD cover
Remote Controller	RMC-200	000-012-629	1	
Spare Parts*	SP19-00101	001-403-170	1 set	
Installation Materials*	CP19-00100	000-012-630	1 set	Power cable
Accessories*	FP19-00601	001-403-200	1 set	

Option

Name	Type	Code No.	Qty	Remarks
Hanger	FP19-00700	001-403-240	1	w/knob, self-tapping screws
Cable Assy	3COX-2P-6C	000-146-500	1	Cable length: 5 m
		000-146-501	1	Cable length: 10 m
	DVI-D/D SINGLELINK5M	000-149-054	1	Cable length: 5 m
Remote Controller	RMC-200	000-012-629	1	

* = See packing list at end of manual.

1 MOUNTING

Refer to the outline drawing at the end of the manual for mounting dimensions.

Note: A glass plate covers the LCD. For this reason, handle the unit carefully.

1.1 Display Unit

The display unit may be mounted on a desktop (optional hanger required) or flush mounted in a panel.

When selecting a mounting location, keep in mind the following points:

- Locate the unit out of direct sunlight.
- Select a location where the display can be easily viewed and the controls can be easily operated.
- Leave sufficient space around the unit for servicing and maintenance. See the outline drawing for minimum servicing space.
- The unit weighs 5.4 kg (flush mounting)/6.3 kg (desktop mounting). Be sure the mounting location is strong enough to support the weight of the unit.
- Locate the unit away from areas subject to water splash and rain.

Flush mounting

See the outline drawing at the end of the manual for mounting dimensions.




CAUTION

Hold the cover and display unit together when lifting the display unit.

The display unit may fall out if only the cover is held.

1. Remove the LCD cover from the unit.
2. Using the paper template supplied in the installation materials, make a cutout in the mounting location.
3. Insert the display unit to the cutout, and fasten the display unit to the mounting location with four self-tapping screws (5x40, supplied as accessories).

Note: Hex head bolts may also be used to fasten the display unit. However, their lengths should be such that they extend at least 10 mm beyond the bulkhead.



Mounting dimensions

4. Attach the cosmetic caps (supplied as accessories) to the display unit at the locations shown in the drawing above.



Desktop mounting

The display unit can be mounted on a desktop, using the optional hanger,
Type: FP19-00700, Code No.: 001-403-240.

Contents of hanger mounting kit

Name	Type	Code No.	Qty
Hanger	FP19-00701	001-403-250	1
Knob bolt	FP19-01402	001-026-770	2
Self-tapping screw	5x20	000-162-608-10	4


1. Fasten the hanger to the mounting location with four self-tapping screws (supplied).
2. Screw knob bolts in hanger, set unit to hanger, and tighten knob bolts.
3. Attach hard cover to protect the LCD.



Desktop mounting

1.2 Remote Controller

Write the device name (ex. "FCV-1200L") for each "signal" key on the sticker supplied with the remote controller. Attach the sticker to the remote controller, at the location shown below.




Remote controller RMC-200

 WARNING	
	<p>Ensure battery polarity is correct.</p> <p>Wrong polarity may cause the batteries to explode.</p>

2 WIRING


Connect external equipment to the MU-120C by referring to the drawings below, the table on the next page and the interconnection diagram at the back of this manual.



Display unit, rear view

Port, cable and connectable equipment

Port Name	Used cable				Connectable Equipment
	Name	Type	Code No.	Standard/Option	
12-24 VDC	Power cable	MJ-A3SPF0025-035C	000-156-059-10	Standard	Power source
DVI-D	DVI Cable	DVI-D/D SINGLELINK5M	000-149-054	Option	PC, FAR-21X7 series, FEA-2107
RGB1	Analog RGB Cable	3COX-2P-6C 5M	000-146-500	Option	FCV-1200L, CH-250, CH-270, CSH-5L/8L, FSV-24/24S/30/30S, GD-280/380/680, FR1510Mk-3, FR-21X5 series, Model 1833C series, Model 1833C-BB series
RGB2		3COX-2P-6C 10M	000-146-501	Option	
VIDEO1	Prepare the following cable locally. ▪ Connector type: RCA (metal), both ends ▪ Cable length: shorter than 10 m ▪ 2.5C2V or 3C2V (Japan Industrial Standard, or the equivalent) coaxial cable (Impedance: 75 Ω)				Video cassette recorder, CCD camera, DVD player
VIDEO2					
VIDEO3					



Grounding

Fasten the ground wire (local supply) between the ground terminal on the display unit and the ship's superstructure. The length should be as short as possible.

Note: Use a "closed-type" lug (🔌) to make the ground connection at the display unit. Do not use an "open-type" lug (🔌).

3 ADJUSTMENTS

Adjust the MU-120C according to the equipment connected. Note that you can adjust the display currently selected, at the DISP selection window. (See section 4.3.)

3.1 RGB/DVI Setting

RGB1 and RGB2 screens can be adjusted independently. Also, DVI screen can be adjusted similarly.

1. Press the [MENU] key to show the main menu.
The main menu is erased automatically with no operation for one minute.
2. Press the [◀] or [▶] key to select RGB1, RGB2 or DVI as appropriate.

RGB1	RGB2	DVI	VIDEO1	VIDEO2	VIDEO3	OSD	SYSTEM
H_SIZE		640					
V_SIZE		480					
PHASE		16	(1 – 32)				
CONTRAST		44	(1 – 64)				
H_POSITION		50	(1 – 99)				
V_POSITION		25	(1 – 40)				
R_LEVEL		31	(1 – 64)				
G_LEVEL		31	(1 – 64)				
B_LEVEL		31	(1 – 64)				
TEMPERATURE		7000K	(5500K/6500K/7000K/8000K)				
B STRETCH		OFF	(OFF, 1 – 10)				
W STRETCH		OFF	(OFF, 1 – 10)				
DISP MODE		FULL	(FULL/EVEN/NORMAL)				
SHARPNESS		5	(1 – 10)				

RGB1 (RGB2) setting menu

RGB1	RGB2	DVI	VIDEO1	VIDEO2	VIDEO3	OSD	SYSTEM
CONTRAST		44	(1 – 64)				
H_POSITION		25	(1 – 50)				
V_POSITION		25	(1 – 40)				
R_LEVEL		31	(1 – 64)				
G_LEVEL		31	(1 – 64)				
B_LEVEL		31	(1 – 64)				
TEMPERATURE		7000K	(5500K/6500K/7000K/8000K)				
B STRETCH		OFF	(OFF, 1 – 10)				
W STRETCH		OFF	(OFF, 1 – 10)				
DISP MODE		FULL	(FULL/EVEN/NORMAL)				
SHARPNESS		5	(1 – 10)				

DVI setting menu

3. Press the [▲] or [▼] key to select the item to adjust.
4. Press the [◀] or [▶] key to adjust.

Menu item	Function	Setting range
H_SIZE***	Adjusts the image size horizontally.	Variable depending on signal type
V_SIZE***	Adjusts the image size vertically.	
PHASE	Adjusts the characters and graphic lines.	1-32
CONTRAST	Increases or decrease contrast level.	1-64
H_POSITION	Moves the image position horizontally.	1-50 (DVI), 1-99 (RGB1, 2)
V_POSITION	Moves the image position vertically.	1-40
R_LEVEL	Adjusts red color level.	1-64
G_LEVEL	Adjusts green color level.	1-64
B_LEVEL	Adjusts blue color level.	1-64
TEMPERATURE	Adjusts color temperature.	5500K/6500K/7000K/8000K*
B STRETCH	Reduces noise on black color.	OFF, 1-10
W STRETCH	Emphasizes white color.	OFF, 1-10
DISP MODE	Selects the signal resolution. FULL: Shows the input signal on entire screen. EVEN: Shows the input signal with original size. NORMAL: Shows the input signal with same aspect ratio.	FULL/EVEN/NORMAL**
SHARPNESS	Sharpens the edge horizontally.	1-10

*: Warm color← 5500K, 6500K, 7000K, 8000K → Cold color

**: Select NORMAL to use the SXGA signal from a radar or scanning sonar. Note that both left and right edges may be in black. For VGA and XGA signals, FULL and NORMAL are available.

***: Adjust H_SIZE and V_SIZE properly. Otherwise, unwanted image may appear outside of the display area.

Note: When the characters are not clear, adjust PHASE and SHARPNESS.

3.2 VIDEO Setting

VIDEO1, VIDEO2 and VIDEO3 screens; that is, the picture-in-picture windows can be adjusted as below.


1. Press the [MENU] key to show the menu.
2. Press [◀] or [▶] to select VIDEO1, VIDEO2 or VIDEO3 as appropriate.

RGB1	RGB2	DVI	VIDEO1	VIDEO2	VIDEO3	OSD	SYSTEM
			PIP_SIZE	5	(1 – 10)		
			CONTRAST	44	(1 – 64)		
			R_LEVEL	31	(1 – 64)		
			G_LEVEL	31	(1 – 64)		
			B_LEVEL	31	(1 – 64)		
			TEMPERATURE	7000K	(5500K/6500K/7000K/8000K)		
			B STRETCH	OFF	(OFF, 1 – 10)		
			W STRETCH	OFF	(OFF, 1 – 10)		

VIDEO1 (2 or 3) setting menu

3. Press the [▲] or [▼] key to select the item to adjust.
4. Press the [◀] or [▶] key to set.

Menu item	Function	Available range
PIP_SIZE	Adjusts the size of picture-in-picture window.	1(25 mmx18mm) - 10 (160 mmx129mm)
CONTRAST	Increases or decrease contrast level.	1-64
R_LEVEL	Adjusts red color level.	1-64
G_LEVEL	Adjusts green color level.	1-64
B_LEVEL	Adjusts blue color level.	1-64
TEMPERATURE	Adjusts color temperature.	5500K/6500K/7000K/8000K
B STRETCH	Reduces noise on black color.	OFF, 1-10
W STRETCH	Emphasizes white color.	OFF, 1-10




Picture-in-picture window

3.3 Menu Window Setting

3.3.1 Adjusting the menu window

The menu window can be moved and translucitized on the OSD (On Screen Display) menu.

1. Press the [MENU] key to show the menu.
2. Press the [◀] or [▶] key to select OSD.



OSD menu


3. Press [▲] or [▼] to select the menu item you want to adjust.
4. Press [◀] or [▶] to adjust.

Menu item	Function	Available range
H_POSITION	Moves the menu window horizontally.	1-22 (1: left, 22: right)
V_POSITION	Moves the menu window vertically.	1-23 (1: up, 23: down)
TRANSLUCENT	Translucitizes the menu window.	Off, On
CUSTOM NAME	See the next section.	

3.3.2 Changing the signal name

You can change the signal name which is shown on the DISP or PIP menu, described in the next chapter. It is useful to use the name of the device connected (ex. "FCV-1200L"). For detailed information about these menus, see Chapter 4.

1. Press the [MENU] key to show the main menu.
2. Press the [►] key to choose the OSD menu.




OSD menu

3. Press the [▲] or [▼] key to select the signal to change its name in CUSTOM NAME area. In the example above, RGB1 is chosen.
4. Press the [►] key to select the character you want to change. In the example below, "G" is selected.



5. Press the [▲] or [▼] key to select appropriate alphanumeric character. In the example below, "5" is selected.




6. To change another signal name, press [◀] and then press [▲] or [▼] to select it.

3.4 Remote Controller Setting

A remote controller can be set to be operative with a specific display unit, in the case of multiple MU-120C display units. Set the remote controller mode desired on the SYSTEM menu as follows;

1. Press the [MENU] key to show the main menu.
2. Press the [▶] key to select SYSTEM.




SYSTEM menu

3. Select INFRARED REMOTE.
4. Point the remote controller toward the display unit, and press any key on the remote controller. The current setting of remote controller is shown inside the remote controller setting square.
5. Press the [RGB2] and [BRILL +] keys together on the remote controller to change the remote controller ID among A, B, C and D.
Your selection appears inside the square.
6. Press the [◀] or [▶] key so that the display unit ID is the same as the remote controller ID in the square.
7. Press the [MENU] key to close the menu.

4 OPERATION

4.1 Controls

Display unit



Display unit


Power key: Press the power key (⏻) to turn the power on or off.

LED: The LED changes color according to signal status as below.

Green: The selected signal to be displayed is input correctly from the external device.

Orange: The selected signal to be displayed is not input from the external device for five seconds.

Remote controller



Remote controller

Key name	Function
RGB1*	Shows the RGB1 signal.
RGB2*	Shows the RGB2 signal.
DVI	Shows the DVI signal.
VIDEO1**	Shows the VIDEO1 signal on the entire screen.
VIDEO2**	Shows the VIDEO2 signal on the entire screen.
VIDEO3**	Shows the VIDEO3 signal on the entire screen.
PIP1***	Shows the VIDEO1 signal in the picture-in-picture window.
PIP2***	Shows the VIDEO2 in the picture-in-picture window.
PIP3***	Shows the VIDEO3 in the picture-in-picture window.
BRILL (+)	Increases the display brilliance.
BRILL (-)	Decreases the display brilliance.
MENU	Shows the main menu.
Arrow keys	Selects the menu items.

*: When a picture-in picture window is shown, it remains on the RGB1 (2).

**: When the previous selection is PIP1, 2 or 3, it is erased by pressing these keys.


***: When the previous selection is VIDEO1, 2 or 3, these keys are not available.

For PIP (picture-in-picture), see “3.2 VIDEO Setting”.

4.2 Adjusting Display Brilliance

The display brilliance can be adjusted as follows.

1. Press the [BRILL] key on the display unit to show the BRILL adjustment window.



BRILL window

3. Press the [◀] or [▶] key to adjust the brilliance. (Setting range: 1 to 50)
You can also adjust brilliance by pressing the [BRILL] key.
4. Press the [▲] or [▼] key to close the window.
The window is erased when there is no operation within five seconds.

Note: Avoid excessively low brilliance to prevent display irregularities.

4.3 Choosing Source for Main Picture

Choose the signal to display on the entire screen as follows:

1. Press the [DISP] key to show the DISP selection window.
Signal names can be changed. For detail, see “3.3.2 Changing the signal name”.



DISP selection window

2. Press the [▲] or [▼] key to select a signal.
You can also select the signal by pressing the [DISP] key continuously.
RGB1-2: The signal from the chosen RGB port is displayed on the entire screen.
DVI: The signal from the DVI port is displayed on the entire screen.
VIDEO1-3: The external video from the appropriate VIDEO port is displayed on the entire screen.
3. Press the [◀] or [▶] key to close the window.
The window is erased when there is no operation within five seconds.

Note: The name of the selected signal appears at the right top corner for five seconds after the DISP menu is erased.

4.4 Choosing Source for Picture-in-Picture

Choose the source for the picture-in-picture window as follows:

Note: The size of the picture-in-picture window can be adjusted on the VIDEO1, 2 and 3 menus. For details, see section 3.2.

1. With the RGB1, RGB2 or DVI display shown, press the [PIP] key.
The PIP selection window appears. Signal names can be changed. For detail, see “3.3.2 Changing the signal name”.




PIP window

2. Press the [▲] or [▼] key to select the VIDEO port desired.
VIDEO can be also selected by pressing the [PIP] key continuously. To turn off the picture-in-picture window, choose OFF.
3. Press the [◀] or [▶] key to close the window.

Note: The picture-in-picture window can be moved by pressing the arrow keys when a menu window is erased.

5 MAINTENANCE, TROUBLESHOOTING



5.1 Maintenance

Routine maintenance

Regular maintenance is important for good performance. Check the following on a regular basis to keep the equipment in good operating condition.

- Check that the connectors at the rear of the display unit are tightly fastened.
- Check the ground wire and ground terminal for rust. Clean if necessary. Confirm that the ground wire is tightly fastened.
- Remove dust and dirt from the display unit and LCD with a dry, soft cloth. Do not use chemical cleaners to clean any part of the display unit – they can remove paint and markings.
- Wipe the LCD carefully to prevent scratching, using tissue paper and an LCD cleaner. To remove dirt or salt deposits, use an LCD cleaner, wiping slowly with tissue paper so as to dissolve the dirt or salt. Change paper frequently so the salt or dirt will not scratch the LCD. Do not use solvents such as thinner, acetone or benzene for cleaning.

Fuse replacement


The 7 A fuse in the power cable protects the equipment from internal fault and overcurrent. If the fuse blows, find the cause before replacing it. If the fuse blows again after replacement, request service.



Battery replacement

The remote controller has two AA batteries. If the distance from which the remote controller can be operated has decreased, change the battery.

Note: Replace all batteries together. Do not mix old and new batteries.




5.2 Troubleshooting

The table below provides troubleshooting procedures to use when no picture appears. If you cannot restore the picture, do not attempt to check inside the equipment – there are no user serviceable parts inside. Refer any work to a qualified technician.

Troubleshooting table

Reason for no picture	Remedy
Ship's battery voltage too high	Check battery voltage.
Fuse has blown.	Replace fuse.
Cable between MU-120C and external equipment has loosened.	Refasten cable.
Power cable has loosened.	Refasten cable.

You can confirm which signals are currently input in the SYSTEM menu.



SYSTEM menu

5.3 Clearing the Memory

You may want to clear the memory to start afresh with default settings. You can do this as follows:

1. Press the [MENU] key to show the main menu.
2. Press the [▶] keys to open the SYSTEM menu.
3. Select DEFAULT RESET by arrow keys.
4. Press the [▶] key to select YES.



SYSTEM menu

5. Press the [▶] key again to select “reset”.

SPECIFICATIONS OF MULTI-PURPOSE LCD DISPLAY MU-120C

1 GENERAL

1.1	Display	12.1 inch SVGA color TFT-LCD, 246 x 185 mm
1.2	Brightness	1,000 cd/m ² maximum, 5 cd/m ² minimum
1.3	Resolution	800 x 600 (SVGA)
1.4	Viewing angle	left/right: 70°, up: 60°, down: 50°
1.5	Input signal	RGB ports: VESA (VGA, SVGA, XGA, SXGA) (0.7Vp-p, Synchronization: TTL level) DVI port: VESA (VGA, SVGA, XGA, SXGA) VIDEO ports: NTSC/PAL

2 POWER SUPPLY

12-24 VDC: 4.0-2.0 A

3 ENVIRONMENTAL CONDITION

3.1	Ambient temperature	
	Display unit	-15°C to +55°C
	Remote controller	+5°C to +35°C
3.2	Relative humidity	93% at +40°C
3.3	Waterproofing	
	Display unit	IPX5 (front panel), IP20 (rear panel)
	Remote controller	IPX0
3.4	Bearing vibration	IEC 60945-4


4 COATING COLOR





N2.5 (not changed)


PACKING LIST MU-120C-J/E


19AR-X-9851 -4

1/1


NAME	OUTLINE	DESCRIPTION/CODE	Q'TY
ユニット			
LCD表示器		MU-120C	1
MULTI-PURPOSE LCD DISPLAY		000-012-628-00	



リモコンセット		REMOTE CONTROLLER SET		RMC-200	
リモコン/リマーク		19-024-1313-0	1		
STICKER		100-315-270-00			
リモコンケース		14-034-2075-1	1		
VINYL CASE FOR REMOTE CONTROLLER		100-292-801-10			
リモコンユニット		RMC-200	1		
REMOTE CONTROLLER		000-149-069-00			
BATT(MN)		R6PKRCP-2	1		
SIZE AA BATTERY		000-142-527-00			

予備品		SPARE PARTS	
予備品		SP19-00101	1
SPARE PARTS		001-403-170-00	

付属品		ACCESSORIES	
付属品		FP19-00601	1
ACCESSORIES		001-403-200-00	

1..コード番号末尾の["**"]は、選択品の代表型式/コードを表します。
CODE NUMBER ENDED BY "***" INDICATES THE NUMBER OF TYPICAL MATERIAL.

NAME	OUTLINE	DESCRIPTION/CODE	Q'TY
工事材料			
ケーブル組品MJ		MJ-A3SPF0025-035C	1
CABLE ASSY.		000-156-059-10	

図書		DOCUMENT	
取扱説明書		OM*-20290-*	1
OPERATOR'S MANUAL		000-149-089-1*	
型紙		C22-00304-*	1
TEMPLATE		000-149-091-1*	

A-1

型式/コード番号が2段の場合、下段より上段に代わる過渡期品であり、どちらが入っています。なお、品質は変わりません。
TWO TYPES AND CODES MAY BE LISTED FOR AN ITEM. THE LOWER PRODUCT MAY BE SHIPPED IN PLACE OF THE UPPER PRODUCT. QUALITY IS THE SAME.
19AR-X-9851

(略図の寸法は、参考値です。DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

CODE NO.	001-403-170-00	19AR-X-9301 -1 1/1
TYPE	SP19-00101	BOX NO. P

[illegible]



(略図の寸法は、参考値です。 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

型式/コード番号が2段の場合、下段より上段に代わる過渡期品であり、どちらかが入っています。なお、品質は変わりません。

TWO TYPES AND CODES MAY BE LISTED FOR AN ITEM. THE LOWER PRODUCT MAY BE SHIPPED IN PLACE OF THE UPPER PRODUCT. QUALITY IS THE SAME.

FURUNO

CODE NO.	001-403-200-00	19AR-X-9501 -6
TYPE	FP19-00601	1/1

付属品表						
ACCESSORIES						
番 号 NO.	名 称 NAME	略 図 OUTLINE	型名 / 規格 DESCRIPTIONS		数量 Q' TY	用途 / 備考 REMARKS
1	ハ° ネルカハ° -(12) COSMETIC CAP				4	
			19-024-1502-0			
			CODE NO.	100-342-140-10		
2	+トラスタッピ° ンネジ° 1ｼｭ SELF-TAPPING SCREW				4	
			5X40 SUS304			
			CODE NO.	000-162-611-10		



型式/コード 番号が 2 段の場合、下段より上段に代わる過渡期品であり、どちらかが入っています。 なお、品質は変わりません。

TWO TYPES AND CODES MAY BE LISTED FOR AN ITEM. THE LOWER PRODUCT MAY BE SHIPPED IN PLACE OF THE UPPER PRODUCT. QUALITY IS THE SAME.

(略図の寸法は、参考値です。 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

表 1 TABLE 1

寸法区分 (mm) DIMENSIONS	公差 (mm) TOLERANCE
0 < L ≤ 50	± 1.5
50 < L ≤ 100	± 2.5
100 < L ≤ 500	± 3




電源コネクタ
POWER CONNECTOR

7-ス端子
GND TERMINAL

銘板
NAMEPLATE

矢視 A
VIEW A



取付穴寸法図
CUTOUT DIMENSIONS

- 注 記 1) 指定外の寸法公差は表 1 による。
2) 取付用ネジは + タッピンネジ呼び径 5 × 4.0 を使用のこと。
- NOTE 1. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS WHICH IS NOT SPECIFIED.
2. USE SELF-TAPPING SCREWS 5X4.0 FOR FIXING THE UNIT.

DRAWN	JUNE 18, '04 E. MIYOSHI	TITLE	MU-120C
CHECKED	TAKAHASHI, T	名称	12.1 型カラー-LCD 表示器 (埋込装備)
APPROVED	Y. Hatai	外寸図	
SCALE	1/5	NAME	MULTI-PURPOSE LCD DISPLAY (FLUSH MOUNT)
DWG. No.	C2029-G01-D		OUTLINE DRAWING

270±0.5







表1 TABLE 1

寸法区分 (mm) DIMENSIONS	公差 (mm) TOLERANCE
0 < L ≤ 50	±1.5
50 < L ≤ 100	±2.5
100 < L ≤ 500	±3

注記 1) # 印寸法は最小サービス空間寸法とする。

2) 指定外の寸法公差は表1による。


3) 取付用ネジは＋トラスタッピンネジ呼び径5×20を使用のこと。

NOTE 1. # MINIMUM SERVICE CLEARANCE.

2. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS WHICH IS NOT SPECIFIED.

3. USE SELF-TAPPING SCREWS 5X20 FOR FIXING THE UNIT.

DRAWN	Mar. 19 '04	E. MIYOSHI	TITLE	MU-120C
CHECKED		TAKAHASHI, T	名称	12.1型カラーLCD表示器 (卓上装備)
APPROVED		Y. Hatai	外寸図	
SCALE	1/5	MASS 6.3 kg	NAME	MULTI-PURPOSE LCD DISPLAY (DESKTOP MOUNT)
DWG.No.	C2029-G02-C	19-024-110G-1	OUTLINE DRAWING	



DRAWN	May 28 '07 T. YAMASAKI			TITLE	MU-120C
CHECKED	May 29 '07 T. TAKENO			名称	12.1型カラーLCD表示器
APPROVED	Jun 05 '07 R. Esumi				相互結線図
				NAME	MULTI-PURPOSE LCD DISPLAY
DWG. No.	C2029-001-D		19-024-5000-1		INTERCONNECTION DIAGRAM



(Elemental Chlorine Free)

The paper used in this manual
is elemental chlorine free.

© **FURUNO ELECTRIC CO., LTD.**

9-52 Ashihara-cho,
Nishinomiya, 662-8580, JAPAN

Telephone : +81-(0) 798-65-2111
Fax : +81-(0) 798-65-4200

• FURUNO Authorized Distributor/Dealer

All rights reserved. Printed in Japan

Pub. No. OME-20290-B

(YOTA) MU-120C

A : MAR. 2004

B : SEP. 05, 2007



* 0 0 0 1 4 9 0 9 0 1 1 *